




2.9.2 AVI VIDEO FORMAT

SAVE AVI FORMAT	
Description	<p>Save is a way that you can save video the footage to hard drive so it will not be overwritten. You can then save the footage on to a compact disc, or save still images of a particular camera to a floppy disk or compact disk.</p> <p>To save a full motion video file follow the same step, but in the Save as type in drop down box, choose the Save as AVI.</p>
	<p>To the save as AVI, do the following:</p> <ol style="list-style-type: none"> Click on the SAVE button on the SEARCH Window screen. Choose the Save as AVI on the drop down menu.(Shown below)  <ol style="list-style-type: none"> AVI backup dialog will appear. (Shown below) <div style="text-align: center;">  <p>AVI Backup</p> </div>

	<ul style="list-style-type: none"> d. Choose the Camera Channel. e. Set Start Time. f. Set End Time. g. Click on the AUDIO RECORDING for Audio record with image. <ul style="list-style-type: none"> ✓ In the motion recording, audio synchronization with video is done automatically. Audio Synchronization can not be perfect. h. Choose the Media to save, If you need the folder name, fill in the folder name. i. Click on the Start Recording button, AVI format creating will start. 		
<p>AVI save sequence</p>	<p>[NOTICE] Audio Synchronization Function. Audio synchronization with Video is done automatically. But this is done when at least 1 fps is saved, So users have to save at least 1 fps. So in Motion recording, Audio Synchronization can not be perfect.</p>		
	<p>Progress rate bar will appear after clicking on the START RECORDING button, AVI file (full motion video clip) will save to the chosen folder.</p> <div data-bbox="451 800 1409 999" style="border: 1px solid black; padding: 5px;"> <p>Backup Status</p> <p>Progress Rate </p> </div>		
	<p>Exit program dialog will be appearing after click on the EXIT button in the AVI Backup dialog. (Shown below)</p> <div data-bbox="451 1077 764 1287" style="border: 1px solid black; padding: 5px;"> <p>AVIRecorder</p> <p>! Warn to Exit Program?</p> <p><input type="button" value="Yes"/> <input type="button" value="No"/></p> </div> <p>Click on the YES button to exit Save as AVI.</p>		
<p>[NOTICE] Backup Media</p> <ol style="list-style-type: none"> 1.Default: Backup in the root, C:_backup in Local HDD(Can be used again) CD/DVD: CD R/RW,DVD R/RW 2. External: Backup in USB external HDD or other external storage. When users named the folder, all backup files are saved in the <time/date> folder when backup. In this <time/date> folder, all backup data are saved as <time/date>.file. 3. When users did not name the folder, <time/date> folder is made and in this all data are saved, all backup data are saved as <time/date>.file. <p>AVI File Play Using Window Media Player, users can play backup AVI File just double-clicking when WMP is installed in the system.</p>			
<p>SAVED FOLDER MANAGEMENT</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">Description</td> <td>To management saved AVI files in backup media, which is very useful to AVI playback.</td> </tr> </table> <p>Management dialog will be appearing after click MANAGEMENT button. (Shown next page) Saved AVI backup data save on to others Media or folder and delete it on this dialog. Also display the available backup media space.</p>		Description	To management saved AVI files in backup media, which is very useful to AVI playback.
Description	To management saved AVI files in backup media, which is very useful to AVI playback.		