

Troubleshooting

DVR Turning off and on

This may occur for several reasons:

Overheating- is usually the main cause of this malfunction.

To prevent this, make sure that all exhaust ports on the DVR are clear and free from obstructions.

Make sure that the DVR is in a clean, dry, temperature-controlled environment.

Enclosed spaces are not recommended for the system, but if absolutely necessary, make sure there is plenty of ventilation. If necessary, blow off dust from exhaust ports with a can of air.

If this does not resolve your issues, please contact the office for further assistance.